

LIGHTING FIXTURE COMPANY

ASSEMBLY AND INSTALLATION INSTRUCTIONS for the 3711 Fixture

Important Safety information (Please read before proceeding)


1. Remove the fixture, parts and all mounting hardware bags (orange) from the carton and verify that all parts are present according to the illustration sheet. All parts must be used as indicated. Do not replace any parts, leave any parts out, or use any parts which are worn out or broken. Failure to follow the instructions could cause a hazardous situation, voids the warranty and violates the U.L. listing of the fixture.

2. To prevent the electric shock, turn off the main power at the circuit breaker before installing the fixture. NEVER attempt to install, clean or replace bulbs without shutting off the electricity to the fixture.

3. Never use light bulbs with wattage ratings that exceed the fixtures maximum rating. Always make sure the electric current is turned off before changing the bulbs.

4. If you experience difficulties installing the lighting fixture or it fails to work as expected, please contact a local qualified licensed electrical contractor.

5. Please contact your local Capital Lighting Fixture reseller with any assembly or installation questions. Your local reseller can also provide you with replacement parts for your new fixture.



Components

- 01. Universal Bar
 02. Outet Box Mounting Screws
 03. Mounting Screws
 04. Allan Wrench
 05. Fixture
 06. Socket
 07. Glass Shade
 08. Socket Ring
 09. Decor Screw

Assembly Instructions for the 3711 fixture

1. Attach Universal Bar with fixture mounting tabs vertically (01) to Outlet Box with Outlet Box Mounting Screws (02).

2. Connect the bare canopy grounding wire and the yellow/green lamp holder ground wire to the outlet box grounding wire with the wire connector supplied; connect white fixture wire to the white power supply wire with wire connector supplied; connect black fixture wire to the black power supply wire with wire connector supplied.

3. Push Fixture (05) to wall, make sure mounting holes in Fixture canopy and Universal Bar (01) are in line, verify all wires are securely inside fixture back plate, and then secure fixture to wall with Mounting Screws (03) and Allan Wrench (04).

4. Raise Glass Shade (07) over Socket (06) onto glass holder of Fixture (05), then secure it with Socket Ring (08).

5. Decor Screws (09) are decorative parts only, please don't overexert.